# US UK

#### Dear user

Thank you for choosing **REDRAGON** product. To protect your rights and for better customer service, please read the following warranty rules carefully. 1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included. 2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.

# **OS Support**

Slide the switch button at left side of keyboard for MAC/WIN OS Support OS list: Windows XP/ Vista/ Win 7/ Win 8/ Win 10/Win 11/Mac OS

#### How to connect the keyboard with a computer Wired Connection

- 1. Slide the 2.4G/OFF/BT switch on left side of the keyboard to OFF.
- Take out the USB A to USB Type C cable in the package and connect the keyboard with your computer, the LED marked with M twinkle in 5 times indicated the conencting
- sucessful.
- The computer will recognize and configure the keyboard automatically.
   Once the keyboard is powered up, charging begins. The LED marked with M lights on
- red.
- 5. It will turn to green when keyboard is fully recharged.

# 2.4G Wireless Connection

- 1. Slide the 2.4G/OFF/BT switch on left side of keyboard to 2.4G.
- press [FN]+[4] for about 3 seconds, the LED marked with M flashes quickly in yellow, plug the USB receiver into any available USB port on your computer within 20 seconds. The computer will recognize and configure the keyboard automatically.
- 3. The indicator will flash on Red when the battery is low. Please recharge the keyboard in time by plug type C cable into computer or it will turn off automatically soon, Please note LED marked with M will be light on Red while charging, it turn to Green when charging completed (In 2.4G connecting mode).

#### **Bluetooth Connection**

 Slide the 2.4G/OFF/BT switch on left side of keyboard to BT.
 Press [FN]+[1](or [2]/[3] for other Bluetooth devices), the LED marked with M flashes in blue (or cyan/magenta for the others).

2

# Turn on Bluetooth and scan for available devices on your computer or smart phone. It will find "BT3.0 Keyboard or BT5.0 KB" device. Select one of them to get connected with it automatically.

4. The indicator "O D" will flash in Red when the battery is low. Please recharge the keyboard in time by plug type C cable into computer or it will turn off automatically soon, Please note LED marked with M will be light on Red while charging, it turn to cyan/magenta when charging completed (In Bluetooth connecting mode).

## Keyboard sleep mode and power safe function

In 2.4Ghz and Bluetooth connecting, to safe power, there are two coditions that keyboard get into sleep mode, all LEDs and backlight turn OFF, **please click any key to wake up the keyboard.** 

- 1. power save mode at the first 3 minutes out of working, all backlight turns OFF, keyboard is working, 2.4G connecting is activity.
- 2. Sleep mode at the 30 minutes out of working, backlight turns OFF, keyboard is OFF, 2.4G is not connecting.

# **Backlight setting**

[FN]+Right[Shift]: Change backlight mode. There are 20 backlight patterns.
[FN]+[Enter]: Change backlight color under available patterns.
[FN]+[Enter]: Slow down the backlight rotating speed.
[FN] + [→]: Add up the backlight rotating speed.
[FN] + [ ↑ ]: Level Up the backlight brightness.
[FN] + [ ↓ ]: Level down the backlight brightness.
[FN] + [ ↓ ]: Level down the backlight brightness.
[FN] + [FN] + [Sace]: Turn ON/OFF backlight.
[FN] + [ESC]: Press and hold for 3 seconds to factory setting.

3

#### FAQ

 If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.

1

2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use.

#### BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.

- DO NOT use this product if the battery shows signs of damage including, but not limited
- to tearing, deformation, leakage, or the smell of electrolytic material. DO NOT touch the battery fi material is leaking and seek immediate medical attention if
- any material comes into contact with your skin or eyes.
- DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.
- DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.
- DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful.

Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.



comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

**Cet appareil contient des émetteurs** / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.



6

## FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

# **California Proposition 65**

MWARNING: Risk of Cancer from [Name of one or more chemicals known to cause cancer] And Reproductive Harm From [Name of one or more chemicals known to cause reproductive toxicity] Exposure - www.P65Warnings.ca.gov



型号 K649CT-RGB-PRO/8882 备流 名称 说明书 日期 2023-3-2(修改) 页码 1 OF 1 文件 绘图 雷国建 审核

# **Backlight recording function**

- 1. Press FN+Backspace, ESC  $\land$  A  $\land$  D  $\lor$  W,  $\uparrow$   $\lor$   $\lor$   $\leftrightarrow$   $\rightarrow$  keys light ON indication its ready for recording.
- 2. Press FN+Backspace again to get ready for recording.
- 3. Keep press the desired key to choose lighting color, The indicator **A** keep flash during the recording, press FN+Backspace to save and quit.

#### Commands of key combinations in MAC with FN key

FN+F1=My computer FN+F2=Homepage FN+F3=Calculater FN+F4=Media Player FN+F5=Previous track FN+F5=Previous track FN+F7=Play/Pause FN+F8=Stop FN+F9=Mute FN+F10=Volume+ FN+F11=Volume+ FN+F11=Email

# How to recharge the keyboard

Find the USB A to USB type C cable in the packaging, plug the keyboard and connect it with computer for charging, the LED indicator(**M**) of keyboard will be turn to red for under 20% power, Purple for under 40% power, blue for under 60% power, cyan for under 80% power,Green is for 80%+power.

Battery statu indication: Press FN+ALT, all backlight turn OFF.

The Number keys from [1!] - [0)] are indicator of power statu as from 0%-100%, when [1!] - [3#] are ON red means keyboard is low power, need to be charge ASAP.





